



**WE CAN HELP!**

**How many fall risk patients are you caring for? How often can you check on them?**

# Basic-Check™

- **Monitor chair, toilet, wheelchair, or bed.** (Uses any Bed-Check® Sensormat®)
- **No on-off switch to remember. Monitors automatically.** Helps you meet JCAHO requirements.
- **Total portability.** Common, easily replaced 9 volt battery.
- **No settings or adjustments.** Just a reset button that silences the alarm and puts the system on hold until weight is again sensed on the Sensormat.
- **Low battery charge alert** (a low continuous tone).
- Meets the same **UL® and CSA Standards** as our other monitors.
- Engineered to withstand extreme environmental static discharge.
- **100% tested** before shipment.
- **Rugged design with integral hanger and Velcro®.**

## In a Chair



Chair Sensormat

## On a Toilet



Potty-Check® Sensormat

## In a Bed



Bed Sensormat

*Weight on Sensormat, Basic-Check monitors. Weight off Sensormat, Basic-Check alarms. Push button to hold till weight is back on Sensormat.*

**Simple. Easy. Basic.**  
The new Basic-Check,  
from Bed-Check Corporation



**Purpose:** The Basic-Check Control Unit is intended to be used in conjunction with a Bed-Check Sensormat<sup>®</sup> as a system for the monitoring of fall risk patients or residents in a bed, chair, wheelchair, or on a toilet. Basic-Check provides an audible alarm to alert the caregiver when the person begins to get up unassisted.

**Components:** The System consists of the Basic-Check Control Unit, and a pressure sensitive Sensormat (ordered separately) with a cord that connects to the Basic-Check. Sensormats are available for bed, chair/wheelchair, and toilet. The Basic-Check has a convenient integral hanger, and a Velcro<sup>®</sup> strip.

**Power requirements:** Basic-Check is powered by a common nine volt alkaline battery. Expected battery life is normally over a year unless alarming is very frequent.

**Installation:** The Basic-Check is hung on the bed headboard or frame, the chair/wheelchair back, or wherever convenient adjacent to the toilet. It should be inaccessible to the monitored person. The appropriate Sensormat is installed per its Technical Bulletin. See the Basic-Check User Guide for complete instructions.

**In-Service:** As with all Bed-Check Corporation products, complete personal in-servicing is available from your professional Bed-Check Distributor.

**Features and Operation:** The Basic-Check is the easiest and simplest of all Bed-Check Corporation's Control Units to operate.

- Monitoring begins immediately when patient weight is sensed on the Sensormat.
- If weight is then removed from the Sensormat, the Basic-Check immediately sounds an audible alarm tone.
- Weight back on the Sensormat silences the alarm, and monitoring resumes.
- Pushing the reset button silences the alarm and puts the system on hold until weight is again sensed on the Sensormat.
- A low continuous tone warns you when the battery charge is low.

**Options:** The Basic-Check is designed to be a simple and economical Control Unit, and no options are offered. If there are needs not met by the Basic-Check, there are many options and accessories available with other Bed-Check Corporation Control Units.